




USER
MANUAL
MAGNIFYING LAMP
PB-338/368

All rights reserved.


Printed in Canada

TABLE OF CONTENTS

1. INTRODUCTION	01
2. SAFETY PRECAUTIONS	01
3. PARTS AND FEATURES	02
4. OPERATION DIRECTIONS	03
5. CLEANING AND MAINTENANCE	03
6. TROUBLE SHOOTING	03
7. WARRANTY AND SUPPORT	04

Please read this manual carefully before using the product to ensure safe and optimal use.

Our company reserves the right to improve design and modify the products without prior notice.

A decorative wavy line in a golden-brown color, starting from the left edge and curving upwards towards the right, ending at the bottom right corner of the page.

Introduction

This Professional Magnifying Lamp is ideal for salons, studios, and workshops. Featuring a distortion-free lens with 3-diopter or 5-diopter magnification, a flexible spring arm, and a stable tabletop clamp, it provides excellent visibility for precision tasks.

Safety Precautions

- Do not use near water or in damp environments to avoid electrical hazards.
- Always turn off and unplug when adjusting or cleaning the lamp.
- Secure clamp properly to prevent tipping or falling.
- Keep out of reach of children.
- Avoid direct sunlight through the magnifier to prevent fire hazards.
- Use only recommended LEDs.
- Inspect the power cord regularly for signs of damage.
Do not operate if frayed or exposed. Contact service agent for support.
- Do not overload the spring arm with accessories not designed for the lamp.
- Do not force the joints — adjust gently to avoid wear and breakage.
- Store safely when not in use to avoid damage.
- Indoor use only.
- Environment temperature $-5^{\circ}\text{C} \sim 40^{\circ}\text{C}$
- Humidity $\leq 95\%$
- Do not disassemble the magnifier. Unauthorized disassembly may result in electrical hazards, malfunction, or damage to the device.

Failure to comply with these instructions will result in the voiding of the manufacturer's warranty.


Parts and Features

Features


- Dual Magnification: 3D (1.75x) and 5D (2.25x) glass lens
- Adjustable Arm: Spring-assisted for flexible positioning
- Table Clamp: Strong clamp for secure mounting
- Optional Stands: Compatible with circle base and X-stand, selected manicure table
- Professional Use: Ideal for nail techs, estheticians, crafters, and hobbyists

Specifications


- Weight: 6lbs
- Lens Options: 3D and 5D (glass lens)
- Lens Diameter: 125–150mm
- Magnification Power: 1.75x (3D), 2.25x (5D)
- Arm Extension Length: 30"–36"
- Arm Type: Tensioned spring-loaded
- Mounting: Tabletop clamp (included)
- Compatible Stands: Circle stand, X-stand (optional)
- Construction: Metal arms, ABS frame
- Light: LED
- Power Supply: AC 110–240V, 50/60Hz



Circle Stand



X-Stand



Operation Directions

1. Set Up: Place the unit on a level, heat-resistant surface.
2. Add Wax: Place wax directly in the pot or insert a wax can.
3. Power On: Flip the ON/OFF switch to the "I" position.
4. Adjust Heat: Rotate the thermostat to the desired setting (MIN for warming, MAX for melting).
5. Monitor Wax: Wait 15–30 minutes for the wax to melt. Stir occasionally.
6. Use: Once melted, reduce to a warm temperature for application.
7. Turn Off: After use, switch off and unplug. Let the unit cool before cleaning.

Cleaning and Maintenance

To keep your lamp in good condition:

- Lens: Use a microfiber cloth and lens-safe cleaner. Do not use alcohol or abrasive materials.
- Body & Arm: Wipe with a damp cloth. Avoid harsh chemicals.
- Clamp: Check for tightness and clean occasionally to maintain grip.
- Joints/Springs: Apply a small amount of machine oil if arm joints squeak or resist movement.
- Storage: When not in use, cover the lens and collapse the arm to protect moving parts.
- Never immerse any part of the lamp in water.

Trouble Shooting

Problem	Possible Cause	Solution
Lamp does not turn on	Not plugged in / Power switch off	Check outlet and switch
Arm won't stay in position	Spring tension unbalanced / Loose joints	Tighten knobs or springs gently
Clamp doesn't hold lamp firmly	Surface not flat or clamp loose	Retighten on a stable surface
Lens is cloudy or scratched	Improper cleaning	Use lens-safe cloth and store with cover

Warranty and Support

- **Warranty:** This product comes with a year warranty that covers defects in materials and parts. Failure to follow recommended care will void product warranty. Consumer misuse not covered. Inspection Required.
Normal wear and tear not covered. Satisfaction Does Not Apply.
- **Customer Support:** For any issues with assembly, use, or maintenance, please contact our customer service team at **+1 604 438 3399** Monday–Friday, 9:00 AM – 5:00 PM (Local Time) or email to **info@protabeauty.com**
- **Service:** If you need repairs or parts replacement, contact us for assistance.



Do not dispose of old or defective appliances in domestic garbage; this should only be done through public collection points.

▲ Please check the product specification before use. This manual is for reference only. Specifications are subject to change without prior notice.